

1@12.0" 1@18.0"

CELL TO CELL DIMENSION: 2.5" **VOLTAGE: 8V** MAKE: E-Z-GO MODEL: TXT48

INSTALLATION INSTRUCTIONS

Only water batteries after charging. Do not leave unattended.

- 1. Remove existing battery caps.
- 2. Ensure the electrolyte level is covering the plates in each cell. If not, add just enough water to cover the plates.
- 3. Following the diagram above, insert the valves into the vent holes.
- 4. Push straight down on each valve until it snaps into the
- 5. Make sure all tubing remains unobstructed.

SAFETY INFORMATION

- Prior to servicing any vehicle, please turn the key switch to the OFF position.
- Do not service any vehicle while the charger cable is plugged into the vehicle or while it is moving.
- Do not use any metal tools or have anything metal on your body while working over the batteries.
- Wear proper safety protection such as safety glasses, face shield, and rubber gloves when installing or working with batteries.
- If acid comes into contact with your skin, or eyes, flush with water and call a physician imediately.

336-714-0448 | www.batterywatering.com