



PART NUMBER: K1800B-GLFBCTB5SX

VALVE: VB-TB5S

REV. 0 04/16/2018

Note: Attach float to float extension and ship them LOOSE from valves. See QC management for help.





This is a guide to installing a basic kit. The diagram(s) above show the most common configurations. Make sure tubing clears battery cables and all obstructions. Only water batteries after charging

DESCRIPTION	QTY.	SAFETY INFORMATION
Valve	18	<ul> <li>Prior to servicing any vehicle, please turn the key switch to the OFF position.</li> <li>Do not service any vehicle while the charger cable is plugged into the vehicle or while it is moving.</li> <li>Do not use any metal tools or have anything metal on your body while working over the batteries.</li> <li>Wear proper safety protection such as safety glasses, face shield, and rubber gloves when installing or working with batteries.</li> <li>If acid comes into contact with your skin, or eyes, flush with water and call a physician imediately.</li> <li>336-714-0448   www.batterywatering.com</li> </ul>
Tubing	8ft	
T Piece	1	
Dust Cap	1	
Male Connector	1	
End Cap	2	
Float EXT	18	
	Valve Tubing T Piece Dust Cap Male Connector End Cap	Valve18Tubing8ftT Piece1Dust Cap1Male Connector1End Cap2