

| PART #    | DESCRIPTION         | QTY.                  |   |
|-----------|---------------------|-----------------------|---|
| Various   | Low Profile Valve   | 18                    |   |
| 08TUB6BLK | 6mm Tubing          | 13'                   |   |
| 09BDCAP   | Dust Cap            | 1                     |   |
| 08CAP6    | End Cap             | 2                     |   |
| 08T666N   | T Piece 6-6-6       | 1                     | 4 |
| 09MBLU1   | 1/4" Male Connector | 1                     |   |
| -         | -                   | -                     |   |
| -         | -                   | -                     |   |
| 08T666N   | T Piece 6-6-6       | 2<br>1<br>1<br>-<br>- |   |

## INSTALLATION INSTRUCTIONS Only water batteries after charging. Do not leave unattended.

1. Remove existing battery caps.

- 2. Ensure the electrolyte level is covering the plates in each cell. If not, add just enough water to cover the plates.
- 3. Following the diagram above, insert the valves into the vent holes.
- 4. Push straight down on each valve until it snaps into the cell.
- 5. Make sure all tubing remains unobstructed.

## 336-714-0448 www.batterywatering.com