



DRAWING NUMBER: B-24-LP-PA

24 CELL - (WITH OR WITHOUT COVER)

PARTIALLY ASSEMBLED KIT

REV. 5 05/12/2016





| PART # | DESCRIPTION | QTY. |
|-----------|-----------------------------|------|
| Various | 6 Valve String | 3 |
| Various | 6 Valve String w/ Fill Tube | 1 |
| 08TUB6BLK | 6mm Tubing | 4' |
| 08CAP6 | End Cap | 2 |
| - | - | - |
| - | - | - |
| - | - | - |
| _ | _ | _ |

INSTALLATION INSTRUCTIONS

Only water batteries after charging. Do not leave unattended.

- 1. Remove existing battery caps.
- 2. Ensure the electrolyte level is covering the plates in each cell. If not, add just enough water to cover the plates.
- 3. Following the diagram above, insert the valves into the vent holes.
- 4. Push straight down on each valve until it snaps into the cell.
- 5. Make sure all tubing remains unobstructed.

336-714-0448 www.batterywatering.com