

Note: Cells are raised by 6" in this area

PART #	DESCRIPTION	QTY.
Various	Low Profile Valve	32
08TUB6BLK	6mm Tubing	17'
09BDCAP	Dust Cap	1
08CAP6	End Cap	10
08T666N	T Piece 6-6-6	3
09MBLU1	1/4" Male Connector	1
08KR66N	6-6-6-6 Cross	3
-	-	-

INSTALLATION INSTRUCTIONS

Only water batteries after charging. Do not leave unattended.

- 1. Remove existing battery caps.
- 2. Ensure the electrolyte level is covering the plates in each cell. If not, add just enough water to cover the plates.
- 3. Following the diagram above, insert the valves into the vent holes.
- 4. Push straight down on each valve until it snaps into the cell.
- 5. Make sure all tubing remains unobstructed.

336-714-0448 www.batterywatering.com