



# BATTERY WATERING TECHNOLOGIES




THE LEADER IN BATTERY WATERING TECHNOLOGY™

PART NUMBER: K2400B-GLFBCTBTRCR


VALVE: VB-TBY

CELL TO CELL DIMENSION: 2.7"


REV. 0 08/27/2013



1. Place 4 end caps and 2 T-pieces into a 3x3 red ziplock bag
2. Place 9 ft of tubing into a 8x10 ziplock bag and add the 3x3 bag to this bag
- 3 Fully assemble the fill tube and place loose in the bag



4. Assemble 8 strings of 3 valves



This is a guide to installing a partially assembled kit. The diagram(s) above show the most common configurations. Make sure tubing clears battery cables and all obstructions.  
Only water batteries after charging

16 @ 2.35"  
1 @ 18.0"  
1 @ 9.0ft

PART #	DESCRIPTION	QTY.	SAFETY INFORMATION
VB-TBY	Strings of 3 Valves	8	<ul style="list-style-type: none"> <li>• Prior to servicing any vehicle, please turn the key switch to the OFF position.</li> <li>• Do not service any vehicle while the charger cable is plugged into the vehicle or while it is moving.</li> <li>• Do not use any metal tools or have anything metal on your body while working over the batteries.</li> <li>• Wear proper safety protection such as safety glasses, face shield, and rubber gloves when installing or working with batteries.</li> <li>• If acid comes into contact with your skin, or eyes, flush with water and call a physician immediately.</li> </ul>
08TUB6	Tubing	9ft	
08T666N	T Piece	3	
09BDCAP	Dust Cap	1	
09MBLU1	Male Connector	1	
08CAP6	End Cap	4	

336-714-0448 | www.batterywatering.com